

Rear Spoiler Installation Instructions

Thank you for your purchase of a Spoiler and Wing King Product. We are confident that you will be more than satisfied with the quality and finish of your spoiler. We guarantee our spoiler and the paint for as long as you own your car. Please refer to our website www.spoilerandwingking.com or your warranty card for details and registration.

PLEASE READ INSTRUCTIONS AND INSPECT SPOILER THOROUGHLY PRIOR TO INSTALLATION

STEP 1.

After Inspecting your spoiler test fit the spoiler to ensure proper position and fit. Double check color match at this time as well.

STEP 2.

Turn the spoiler over and set it on a soft surface(The packaging foam works great for this). Install Brake Light (when applicable). Install gaskets and or gasket material.

STEP 3.

Place the locator strips onto the threaded inserts on the spoiler and the LED brake light hole (when applicable). A small piece of masking tape is helpful in holding the locator strips in place.

STEP 4.

Place the spoiler on the closed decklid and align to proper position. A measuring tape should be used in this step.

STEP 5.

Using masking tape, secure the locator strips to the decklid of the vehicle. Then remove the spoiler by lifting straight up from the locator strips making sure that the locator strips do not move from the vehicle.

STEP 6.

Using a 1/8" drill bit, drill thru the locator strip holes and into the decklid. Remove locator strips from the vehicle. If the decklid has a double panel, Drill thru the second layer as well.

STEP 7.

Using a 5/16" drill bit (We recommend a Unibit for a cleaner cut), drill thru the 1/8" hole in step 6. If a double panel does exist, use a 1/2" drill bit to drill thru the second layer (this hole must be drilled from the bottom side of the deck lid first). The 1/2" hole allows for the head of the screw to fit thru the second layer.

STEP 8.

Debur all holes and apply rust inhibitor. WD40 works great as rust inhibitor.

STEP 9.

Run brake light wire (where applicable) thru proper hole making sure it does not pinch between the spoiler and deck lid. Place spoiler on decklid and using supplied screws secure spoiler to the vehicle.

STEP 10.

Run brake light wire (when applicable) to existing 3rd brake light . Use a test light to insure you have the proper wires. Make connections and test the light. Finalize the connections with electrical connectors or use solder and tape.

STEP 11.

Finish your install by vacuuming any debris and metal shavings. Then reinstall any panels or mats that were removed prior to installation.

KIT INCLUDES

- Rear Spoiler
- Mounting Gaskets or Gasket Material
- Locator Strips
- Mounting Screws
- LED Brake Light (when applicable)

